

## BONNET CLOSURE.pdf

Reference	SSM66297
Models	F-TYPE / X152
Title	Hood / Bonnet Close Correct Method
Category	Body
Last modified	13-Jun-2013 00:00:00
Symptom	111000 Body Panel(s)/Unibody
<p><b><u>Issue:</u></b> Reports of difficult and, or poor closure of bonnet / hood.</p>	
<p><b>Cause:</b> Incorrect method of closure used. The bonnet / hood should not be closed by standing at the side of the vehicle.</p>	
<p><b>Action:</b> Content The bonnet should always be closed when standing at the front bumper of the car. Apply downwards pressure so the bonnet travels past the tension of the struts and continue to apply pressure until the bonnet latches closed. (See attached photographs for general guidance). Ensure even pressure is applied.</p>	
<p><b><u>Please note:</u></b> If transit protection covers are fitted to the bonnet then it will affect the pressure applied to close successfully.</p>	